

Color screen fog screen machine control system manual

1: Menu description

Main interface	menu content	menu description
1. Address setting	A001-A512	Set the address code and use DMX512 to control this device (1-512)
2. User mode	1. Easy mode 2.433 wireless remote control switch 3. WIFI function switch	1. After this switch is turned off, you will not be able to enter the simple mode interface. 2. This switch is a 433 wireless remote control switch, and it will no longer receive remote control control after it is turned off. 3. This switch is a switch for the WIFI function, and it will no longer accept WIFI control after it is turned off. Note: The remote control function and WIFI function are only valid for the simple mode
3. Manual operation	Adjust various function parameters 1. System switch 2. Hot and cold switch 3. Set air volume (1-9) 4. Set the amount of fog (1-9) 5. Set the timing time (0, 1, 2, 4, 8) (hours)	1. System switch: the device will no longer work after it is turned off. 2. Hot and cold switch: whether to turn on the heating or not. 3. Set the air volume. 4. Set the amount of fog. 5. Set the timing time, 0: no timing, 1, 2, 4, 8: Timing time (hours), when the time is up, the switch state of the device will be flipped, if it is currently on, it will be turned off. Note: This interface can only be operated manually with buttons, and no longer accepts remote control and WIFI control

<p>4. Basic settings</p>	<ol style="list-style-type: none"> 1. Language settings 2. Restore factory settings 3. WIFI configuration 	<ol style="list-style-type: none"> 1. Language setting: currently supports switching between Chinese and English. 2. Restore factory settings: password : provided by the factory. Note: After restoring the factory settings, any parameters such as the administrator password will be restored to the factory value 3. WIFI configuration: To use the WIFI function, you must first enter this interface, when the screen displays Open APP to complete configuration! Open the mobile APP and configure according to the prompts. Note: To use this function, the connected WIFI must be able to connect to the network; After the first configuration is successful, there is no need to configure it again in the future. If the configuration is unsuccessful, you can repeat the operation.
<p>5. Information</p>	<ol style="list-style-type: none"> 1. Software version 2. Cumulative usage time 3. Accumulated fog opening time 4. Error message 	<p>All time is automatically saved once every 3 minutes.</p>
<p>easy mode</p> <p>(You need to press and hold the UP+DOWN buttons at the same time to enter and exit this interface)</p>	<ol style="list-style-type: none"> 1. System switch 2. Hot and cold switch 3. Set air volume (1-9) 4. Set the amount of fog (1-9) 5. Set the timing time (0, 1, 2, 4, 8) (hours) 	<ol style="list-style-type: none"> 1. Press the MENU button to switch the system switch status. 2. Press the ENTER button to switch the heating state. 3. Press the UP button to set the air volume. 4. Press the DOWN button to set the amount of fog. <p>Note: It can be controlled by WIFI and remote control.</p>

Note: In any interface: long press the middle two keys UP+DOWN: enter and exit the simple operation mode menu;

Long press the MENU+ENTER button on both sides to switch between Chinese and English modes.

Two: WIFI function description

1. After the WIFI is configured successfully and the WIFI switch is turned on, the device can be controlled (only in the simple mode).
2. There are 4 switches on the mobile APP:

Switch 1: Device switch, all drivers will no longer work after it is turned off.

Switch 2: Set the air volume, ON: Maximum wind (9); OFF: Intermediate wind (5).

Switch 3: Set the amount of fog, ON: maximum fog (9); OFF: medium fog (5).

Switch 4: heating or not, ON: heating.

Three: 433 remote control function description

1. The remote control must be turned on and it will be valid only in the simple mode.

2. There are 15 buttons on the remote control:

5: Device switch.

1, 2, 3, 4: Timing time setting, corresponding to 1, 2, 4, 8 hours, you must first select the time and press the No. 6 button on the remote control to make the timing setting effective.

7, 8, 9: Adjust the air volume, each button can be adjusted 3 levels in a cycle, a total of 9 levels.

10, 11, 12: Adjust the amount of fog, each button can be adjusted 3 levels in a cycle, a total of 9 levels.

13: Turn off the heating state.

14: Turn on the heating.

15: Clear the timing time.

